PREMIER®

MANUAL DE INSTRUCCIONES
CAFETERA ELÉCTRICA
ED-2136

ESTIMADO CLIENTE

Felicitaciones por su compra! Usted ha elegido el mejor modelo en su clase. Las características tecnológicas, el diseño y las funciones de esta unidad, junto con un estricto cumplimiento de los estándares más altos de calidad, le darán una completa satisfacción por mucho tiempo.

Por favor lea cuidadosamente este manual, y guárdelo para su futura referencia.
Si necesita soporte adicional, no dude en escribir a: ***info@premiermundo.com***

PRIMER USO DE SU CAFETERA

- Antes de preparar café por vez primera, utilice su cafetera una vez únicamente con agua (sin café o filtro).
- Conecte el enchufe a la corriente eléctrica.
- Retire la tapa de la cafetera de vidrio y llénela con agua. Sólo utilice agua fría.
- Ahora viértala en el depósito de agua y ponga la cafetera (con la tapa puesta) de regreso en la base eléctrica caliente.
- Comience el proceso de preparación encendiendo la unidad con el interruptor.

PREPARACIÓN DE CAFÉ

- Levante la tapa del depósito de agua y llene el depósito con agua fría de la llave, dependiendo de la cantidad de tazas que desee preparar. El indicador de nivel le muestra el número de tazas (1 taza=125ml).
- Ubique el filtro permanente en la base para el filtro y llénelo con café molido. Agregue 6 o 7 gramos este café por cada taza.
- Para utilizar la cafetera de vidrio, póngala (con la tapa puesta) en la base caliente y ajuste la base del filtro. La luz se encenderá indicando que la cafetera está funcionando.
- El mecanismo de anti-goteo previene que el filtro gotee después de retirar el recipiente o si se inclina la base del filtro.

LIMPIEZA

- Desconecte siempre la unidad antes de limpiarla.
- Limpie con un trapo húmedo con un poco de detergente.
- No introduzca la unidad en agua u otros líquidos.
- No la coloque bajo el grifo del agua.
- La cafetera de vidrio puede ser lavada con agua tibia, un jabón líquido adecuado y una esponja suave.
- No la ponga en el lavaplatos.

MANTENIMIENTO

Para asegurar que su cafetera continúe preparando un café perfecto, es importante que ocasionalmente retire los residuos minerales que quedan por el agua utilizando un producto específicamente diseñado para este fin en las cafeteras. La frecuencia de este procedimiento dependerá de la dureza del agua que utilice en su cafetera.

Si la utiliza una o dos veces al día, siga la siguiente recomendación:

- Agua suave: cada 6 meses.
- Agua semidura: cada 2 o 3 meses.
- Agua dura: cada 6 u 8 semanas.

PRECAUCIÓN

- Antes de conectar la unidad verifique que el voltaje indicado en la etiqueta en la base de la cafetera corresponde a la corriente eléctrica de su hogar.
- No permita que el cable de corriente toque la base caliente.
- Cuando vaya a preparar café una vez seguida de otra, apague la cafetera y permita que se enfría unos 5 minutos. Luego llénela de nuevo con agua fría.
- El café que se encuentra en la cafetera se mantendrá caliente en la medida en que esté prendida.
- Mantenga la unidad apagada cuando no la esté usando. La luz se apagará indicando que la cafetera no está en operación.

ANOMALÍAS Y REPARACIÓN

- Si encuentra algún daño en el cable eléctrico, no intente repararlo usted mismo.
- No intente reparar, ajustar o reemplazar partes de la unidad. Por favor diríjase al centro de servicio más cercano.

ENGLISH

COFFEE MAkER

ED-2136

DEAR CUSTOMER:

We would like to thank you for purchasing a appliance. By choosing this appliance, you have selected the best model in its class. The technological features, design and functions of this unit –together with strict compliance of the highest quality standards –will provide full satisfaction for a long time.

SAFELY TIPS AND PRECAUTIONS

Please read this instruction brochure carefully before using the appliance.
Unpack the appliance completely and check that it is full working order, since any factory defect or possible damage caused by transportation is covered by the warranty.

WHEN USING THE COFFEE MAKER FOR THE FIRST TIME

Before making coffee for the first time, run the coffee maker once with water only (without coffee or filler).
Plug the coffee maker into the power outlet. Remove the lid from the glass coffee pot and fill it with water. Use only cold water. Pour the water from the coffee pot into the water deposit and put the coffee pot (with the lid on) back on the electric hot plate. Start the coffee making process by turning on the power switch.

TO MAKE COFFEE

Lift the lid of the water deposit and fill the deposit with cold water from the tap, depending on the number of cups of coffee you wish to prepare. The water lever indicator shows the number of cups (1 cup=125ml).
Place the permanent filter in the filter holder and fill it with ground coffee. Put in 6 or 7 grams of ground coffee per cup. To use the glass coffee pot, put it (with the lid on) on the hot plate and position the filter holder. Close the lid of the deposit of water and switch on the appliance. The pilot light will turn on, indicating that the coffee maker is on. The non-drip mechanism prevents the filter from dripping after the recipient is removed or the filter basket is tilted.

CLEANING

Always unplug the coffee maker before cleaning. To clean, wipe with a damp cloth moistened with a few drops of detergent.
Do not immerse the appliance in water or any other liquid.
Do not place it under the tap.
The glass coffee pot may be cleaned with warm water, a washing liquid and soft brush. Do not place in the dishwasher!

DE-SCALING

To ensure your coffee maker continues to make perfect coffee, you should occasionally de-scale the

mineral residue left by water using a de-scaling product specifically formulated for coffee makers. The frequency of this operation will depend on the hardness of the water in you use your coffee maker.
If you use it once or twice a day, use the following as a guideline:
Soft water: every 6 months.
Medium hard water: every 2 or 3 months.
Very hard water: every 6 or 8 weeks.

ATTENTION!

The mains voltage must match the rated voltage listed on the label on the base of the coffee maker.
Use only cold water.
Do not allow the power cord to touch the hot plate.
When making coffee again right away, turn the coffee maker off and let it cool down for about 5 minutes. Then fill it again with cold water.
The coffee in the coffee pot will be kept hot while the coffee maker is on.
Always unplug the coffee maker before cleaning it.
Keep the coffee maker off, use the power switch. The pilot lamp will turn off, indicating that the coffee maker is no longer in use.

ANOMALIES AND REPAIRS

If the power connection is damaged, do not attempt to replace it.
Take the appliance to an authorized Technical Service agent since operation could be hazardous. The same applies for any other anomaly.